

Table of models WAECO MagicSafe MS670

3.08

CAN bus car alarm, models in the table correspond to software version W3

Maker	Model	Functions	Code
Alfa Romeo			
	159, 2005 –	1 2 5 7 9	213
	Brera, 2005 –	1 2 5 7 9	213
	Mito, 2008 –	1 2 6 9	244
Audi			
	A3, 2004 – 2009	1 2 4 5 7 9	220
	A3 Sportback, 2004 –	1 2 4 5 7 9	220
	A3, 2010 –	1 2 3 4 5 7 9	303
	A4, 2002 – 2004	1 2 3 4 5 7 9	256
	A4, 2005 – 2007	1 2 3 4 5 7 9	222
	A4, 2008 –	1 2 3 4 5 7 9	289
	A4 Cabrio, 2005 –	1 2 3 4 5 7 9	248
	A5, 2008 –	1 2 3 4 5 7 9	290
	A6, 2005 – 2006	1 2 3 4 5 7 9	222
	A6, 2007 –	1 2 3 4 5 7 9	277
	A8, 2007 –	1 2 3 5 7 8 9	268
	Q5, 2009 –	1 2 3 4 5 7 9	290
	Q7, 2006 –	1 2 3 4 5 7 9	221
	R8, 2008 –	1 2 3 4 5 7 9	292
	TT, 2006 –	1 2 3 4 5 7 9	252
BMW			
	1er (E87), 2005 – 2008	1 2 5 7 9	234
	1er (E87), 2009 –	1 2 5 7 9	234
	3er (E90), 2005 –	1 2 4 5 7 8 9	234
	3er Coupé (E92), 2006 –	1 2 3 7 8 9	250
	3er Cabrio (E93), 2008 –	1 2 4 5 7 8 9	234
	5er (E60 – E61), 2004 –	1 2 4 5 7 8 9	234
	6er (E63), 2006 –	1 2 3 4 5 7 8 9	250
	7er (E65), 2006 –	1 2 3 4 7 8 9	250
	X5 (E70), 2007 –	1 2 3 4 7 9	250
	X6 (E71), 2008 –	1 2 3 4 7 9	250
Bentley			
	Continental GT, 2008 –	1 2 3 4 5 7 8 9	291
Chevrolet			
	Captiva, 2006 –	1 2 6	257
	Cruze, 2009 –	1 2 6 9	301
Chrysler			
	300 C, 2-key transmitter, 2006 –	1 2 3 9	255
Citroën			
	Berlingo, 2008 – **	1 2 9	247
	C2, 2005 – **	1 2 9	247
	C3, 2005 – 2009 **	1 2 9	247
	C3, 2010 – **	1 2 9	247
	C3 Pluriel, 2005 – **	1 2 9	247
	C4, 2004 – 2005	1 2 9	274
	C4, 2006 – **	1 2 9	247
	C4 Picasso, 2006 – **	1 2 9	247
	C5, 2005 – 2007 **	1 2 9	247
	C5, 2008 – **	1 2 9	247
	C6, 2005 – **	1 2 9	247
	C8, 2005 – **	1 2 9	247
	C-Crosser, 2007 –	1 2 7 8 9	273
	Jumper, 2006 –	1 2 6 9	212
	Jumpy, 2007 – **	1 2 4 5 9	247
	Nemo, 2008 –	1 2 6 9	244
Fiat			
	500, 2007 –	1 2 6 9	244
	Bravo, 2007 –	1 2 6 9	212
	Croma, 2005 –	1 2 7 9	213
	Ducato, 2006 –	1 2 6 9	212
	Fiorino, 2008 –	1 2 6 9	244
	Grande Punto, 2005 – 2008	1 2 6 9	244
	Grande Punto, 2009 –	1 2 6 9	244
	Idea, 2003 – 2007	1 2 4 5 7 9	211
	Idea, 2008 –	1 2 6 9	212
	Panda, 2004 –	1 2* 9	212
	Scudo, 2007 – **	1 2 4 5 9	247
	Stilo, 2001 – 2005	1 2 4 5 7 9	210
	Stilo, 2006 –	1 2 4 6 9	212
Ford			
	Fiesta, 2007 – ***	1 2 6	266
	Focus, 2005 – 2007 ***	1 2	245
	Focus, 2008 –	1 2 3	285
	Focus C-Max, 2005 – ***	1 2	245

** Programming can only be done by an authorised dealer. Cable set 9101600007 is required, please include it in your order.

*** Not for vehicles with original alarm system

Table of models WAECO MagicSafe MS670

3.08

CAN bus car alarm, models in the table correspond to software version W3

Maker	Model	Functions	Code
Honda			
	Fusion, 2007 – 2009 ***	1 2 4	281
	Fusion, 2010 – ***	1 2	266
	Ka, 2009 –	1 2 6 9	244
	Kuga, 2008 –	1 2 6 8	295
	Mondeo, 2007 – ***	1 2 3* 5	262
	S-Max, 2006 – ***	1 2 3 5	262
	Accord, 2007 –	1 2 3* 5	280
	Civic, 2007 –	1 2 3* 5	279
	CR-V, 2007 –	1 2 3* 5	279
	Insight, 2010 –	1 2 3* 5	279
	Jazz, 2010 –	1 2 3* 5	279
Iveco			
	Daily, 2007 –	1 2 6 9	212
Lancia			
	Delta, 2008 –	1 2 6 9	212
	Musa, 2004 – 2007	1 2 4 5 7 9	211
	Musa, 2008 –	1 2 6 9	212
	Ypsilon, 2004 – 2005	1 2 4 5 7 9	211
	Ypsilon, 2006	1 2 7 9	212
	Ypsilon, 2007 –	1 2 7 9	212
Jeep			
	Compass, 2009 –	1 2	254
	Grand Cherokee, 2006 –	1 2 3 7 9	254
Kia			
	Carnival, 2007 –	1 2 7 9	270
	Opirus, 2009 –	1 2 5 6 8	299
Land Rover			
	Freelander 2, 2007 –	1 2 3 5 7 9	269
	Range Rover Sport, 2006 –	1 2 3 5 9	249
Mazda			
	3, 2010 –	1 2 6 8	298
	6, 2008 –	1 2	294
Mercedes-Benz			
	A-Klasse (W169), 2005 –	1 2 5 9	230
	B-Klasse (W245), 2006 –	1 2 5 9	233
	C-Klasse (W203), 2001 – 2006	1 2 3 4 5 7	231
	C-Klasse (W204), 2007 –	1 2 5 7	272
	C-Klasse Sportcoupé (W203), 2001 –	1 2 3 5	231
	CL (W216), 2007 –	1 2 3 5 7 9	228
	CLS (W219), 2007 –	1 2 5 7	229
	E-Klasse (W211), 2005 – 2008	1 2 3 5 7 9	229
	E-Klasse (W212), 2009 –	1 2 5 7	272
	E- Klasse Coupé (W207), 2009 –	1 2 5 7	272
	G-Klasse (W463), 2006 –	1 2 3 5 7	231
	GL-Klasse (X164), 2007 –	1 2 3 5 7	230
	GLK, 2009 –	1 2 3* 5	272
	M-Klasse (W164) 2-key transmitter, 2006 –	1 2 3 4 5	230
	R-Klasse (W251), 2006 –	1 2 3 4 5	230
	S-Klasse (W220), 2000 – 2002	1 2 5 6	258
	S-Klasse (W220), 2003 – 2005	1 2 3 5 7	260
	S-Klasse (W221), 2006 –	1 2 3 5 7 9	228
	CLK (W209), 2004 –	1 2 5 7	231
	SL (R230), 2006 –	1 2 3 5 7 9	260
	SLK (R171), 2004 –	1 2 5 7	231
	Sprinter, 2007 –	1 2 3 5 6	264
	Vito, 2004 –	1 2 5 6	232
	Viano, 2006 –	1 2 5 6	232
Mini			
	Mini, with OE alarm, 2007 –	1 2 3 4 5 7 9	276
	Mini, without OE alarm, 2007 –	1 2 4 7 9	234
Mitsubishi			
	Lancer, 2008 –	129	273
	Outlander, 2007 –	1268	273
Nissan			
	Micra, 2007 –	1 2	283
	Navara, 2007 –	1 2	275
	Note, 2007 –	1 2	283
	Note, 2008 –	1 2 8	275
	Qashqai, 2007 –	1 2 5 8	284
	Qashqai, 2008 –	1 2 5 8	296
	Qashqai, 2009 –	1 2 8	275
	Pathfinder, 2007 –	1 2 3*	275

** Programming can only be done by an authorised dealer. Cable set 9101600007 is required, please include it in your order.

*** Not for vehicles with original alarm system

Table of models WAECO MagicSafe MS670

3.08

CAN bus car alarm, models in the table correspond to software version W3

Maker	Model	Functions	Code
Opel			
	Antrara, 2007 –	1 2 5	257
	Astra (Ver. H), 2004 –	1 2 5 9	225
	Astra (Ver. H), 2007 –	1 2 5 8 9	278
	Corsa (Ver. D), 2006 – 2008	1 2 5 9	227
	Corsa (Ver. D), 2009 –	1 2 5* 9	227
	Insignia, 2009 –	1 2 6 9	300
	Signum, 2002 –	1 2 3 4 5 7 9	226
	Vectra, 2002 –	1 2 3 4 5 7 9	226
	Zafira, 2006 –	1 2 5 8 9	227
Peugeot			
	207, 2007 – **	1 2 9	247
	207CC, 2009 – **	1 2 6* 9	247
	307, 2005 – **	1 2 9	247
	307CC, 2006 – **	1 2 9	247
	308, 2007 – 2008	1 2 9	287
	308, 2009 – **	1 2 9	247
	3008, 2010 –	1 2 9	247
	407, 2005	1 2 9	274
	407, 2006 – **	1 2 9	247
	4007, 2007 –	1 2 7 8 9	273
	5008, 2010 – **	1 2 9	247
	807, 2006 – **	1 2 9	247
	Bipper, 2008 –	1 2 6 9	244
	Boxer, 2006 –	1 2 6 9	212
	Expert, 2007 – **	1 2 4 5 9	247
	Passat, 2001 – 2005	123457	216
Porsche			
	911 (Ver. 997), 2006 –	1 2 3 5 7	253
	Boxster, 2007 –	1 2 3 5 7	253
	Cayenne, 2005 –	1 2 3 4 5 7 8 9	218
	Cayman, 2007 –	1 2 3 5 7	253
Saab			
	9-3 / 9-3 Cabrio / 9-3 SW, 2006 –	1 2 6 9	261
Seat			
	Altea, 2004 –	1 2 3* 4 5 9	242
	Altea XL, 2007 –	1 2 3* 4 5 7 9	242
	Cordoba, 2001 –	1 2 3* 4 5	241
	Exeo, 2009 –	1 2 3* 4 5 7 9	222
	Ibiza, 2001 – 2007	1 2 3* 4 5	243
	Ibiza, 2008 –	1 2 5 7 9	293
	Leon, 2000 – 2005	1 2 3* 4 5	240
	Leon, 2006 – 2009	1 2 3* 4 5 7 9	239
	Leon, 2010 –	1 2 3* 4 5 7 9	302
	Toledo, 2005 –	1 2 3* 4 5 9	238
Skoda			
	Fabia, 2001 – 2006	1 2 3* 4 5	235
	Fabia, 2007 –	1 2 4 5 7	259
	Octavia II, 2004 – 2008	1 2 3* 4 5 7 9	236
	Octavia II, 2009 –	1 2 3 4 5 7 9	293
	Roomster, 2006 –	1 2 4 5 7	259
	Superb, 2003 – 2008	1 2 3* 4 5 7	237
	Superb, 2009 –	1 2 3 4 5 7 9	293
	Yeti, 2010 –	1 2 3 4 5 7 9	302
Subaru			
	Legacy, 2007 –	1 2	282
	Outback, 2007 –	1 2	282
Toyota			
	Auris, 2007 –	1 2 5	263
	Avensis, 2009 –	1 2 5	263
	IQ, 2009 –	1 2 5	263
	Prius, 2010 –	1 2 5 8	263
	RAV4, 2007 –	1 2 5 8	263
	Urban Cruiser, 2010 –	1 2 5 8	263
	Verso, 2009 –	1 2 5	263
	Yaris, 2007 –	1 2 5	263
Volkswagen			
	Caddy, 2005 –	1 2 4 5 7 9	223
	Crafter, 2007 –	1 2 3 5 6	264
	Eos, 2006 –	1 2 3 4 5 7 9	217
	Golf Plus, 2004 –	1 2 3 4 5 7 9	215
	Golf V, 2004 –	1 2 3 4 5 7 9	215
	Golf VI, 2009	1 2 3 4 5 7 9	297
	Golf VI, 2010 –	1 2 3 4 5 7 9	302

** Programming can only be done by an authorised dealer. Cable set 9101600007 is required, please include it in your order.

*** Not for vehicles with original alarm system

Table of models WAECO MagicSafe MS 670

3.08

CAN bus car alarm, models in the table correspond to software version W3

Maker	Model	Functions	Code
Volkswagen			
	Jetta, 2006 –	1 2 3 4 5 7 9	215
	Passat, 2001 – 2005	1 2 3 4 5 7	216
	Passat, 2006 –	1 2 3 4 5 7 9	217
	Passat CC, 2008 –	1 2 3 4 5 7 9	217
	Phaeton, 2006 –	1 2 3 5 7	265
	Polo, 2001 – 2005	1 2 3 4 5 7	219
	Polo, 2006 – 2009	1 2 3 4 5 7	214
	Polo, 2010 –	1 2 3 5 7 9	304
	Scirocco, 2009	1 2 3 4 5 7 9	215
	Scirocco, 2010 –	1 2 3 4 5 7 9	302
	Tiguan, 2008 – 2009	1 2 3 4 5 7 9	217
	Tiguan, 2010 –	1 2 3 4 5 7 9	302
	Touareg, 2005 – 2006	1 2 3 4 5 7 9	218
	Touareg, 2007 –	1 2 3 4 5 7 9	267
	Touran, 2004 –	1 2 3 4 5 7 9	215
	Transporter, 2005 –	1 2 3 4 5 6 9	224
Volvo			
	C30, 2007 –	1 2 6	271
	C70, 2008 –	1 2 5 6	271
	S40, 2006	1 2 6	251
	S40, 2007 –	1 2 6	271
	S80, 2007 –	1 2 5 9	286
	V50, 2006	1 2 6	251
	V50, 2007 –	1 2 6	271
	V70, 2008 –	1 2 5 9	286
	XC60, 2009 –	1 2 3* 5 9	286
	XC70, 2008 –	1 2 5 9	286
	XC90, 2005 –	1 2 3* 5 6 9	246

Alarm functions available via the comfort CAN bus system:

Number / Code	Function
1	Door contact switch
2	Boot contact switch
3	Bonnet contact switch
4	Activation via door lock switch
5	Automatic deactivation (auto relock)
6	Deactivation when the boot lid is opened via the vehicle's original remote control
7	Deactivation when the boot lid is opened via the vehicle's original remote control and subsequent reactivation once the boot lid has been closed
8	Vehicle with "keyless go" system
9	Activation of the indicator lights via a cable link
*	* Depending on the model